

SERBIAN AIR FORCE AND AIR DEFENCE



Display Order

August 2012

CONTENTS

INTRODUCTION	4
1. "BATAJNICA 2012" INTERNATIONAL AIR SHOW	4
2. "BATAJNICA 2012" ACTIVITIES	4
3. PURPOSE AND VALIDITY OF THE "BATAJNICA 2012" DISPLAY ORDER	4
4. HEALTH AND SAFETY	4
5. SECURITY	5
6. PRESS STATEMENTS	5
SECTION 1	6
COMMAND AND CONTROL	6
1. MANAGEMENT OF "BATAJNICA 2012" FLYING OPERATIONS	6
2. AIRCRAFT ADMINISTRATION	6
3. REGULATIONS AND FLIGHT CONTROL	6
4. AIR TRAFFIC CONTROL	6
5. COMUNICATION	6
SECTION 2	8
"BATAJNICA 2012" FLYING REGULATIONS	8
1. INTRODUCTION	8
2. FIXED WING-VERTICAL SEPARATION	8
3. ROTARY WING AND GENERAL AVIATION-VERTICAL SEPARATION	8
4. FIXED WING-LATERAL SEPARATION	8
5. ROTARY WING-LATERAL SEPARATION	9
6. GENERAL RULES	9
7. AUTHORITY TO FLY AT "BATAJNICA 2012".	10
8. AIRCRAFT EQUIPMENT	10
9. CREW LIMITATIONS	10
10. AIRCRAFT DOCUMENTATION	10
11. BOOKING OUT	11
12. DAILY PRE-FLIGHT BRIEFING	11
13. BREACHES OF REGULATIONS	11
SECTION 3	12
AIRFIELD AND AIRSPACE INFORMATION	12
1. AIRFIELD INFORMATION	12
2. AIRFIELD OPERATING HOURS & ASSOCIATED ACTIVITIES	13
3. TIME	13
4. COMMUNICATIONS	14
5. WEATHER INFORMATION	14
6. AIRSPACE	14
SECTION 4	15

ARRIVAL PROCEDURES	15
1. INTRODUCTION	15
2. ROUTES	15
3. PLANNING AND ASSISTANCE	15
4. APPROACH PROCEDURES	15
5. INBOUND FLIGHT PLAN	15
6. PPR/"BATAJNICA 2012" REFERENCE	16
7. TRAFFIC PATTERN (annex C)	16
8. DIVERSION	16
SECTION 5.....	17
AIRFIELD OPERATIONS	17
1. INTRODUCTION	17
2. RAMP OPERATIONS, ENGINEERING SERVICES AND REFUELLING	17
SECTION 6.....	18
FLYING DISPLAY PROCEDURES	18
1. INTRODUCTION	18
2. FLYING DISPLAY –REHERSEAL FLIGHTS	18
3. FLYING DISPLAY PROGRAM	18
4. FLYING DISPLAY PLANNING	18
5. PRE-FLIGHT BRIEFING	19
6. BOOKING OUT AND INITIAL PROCEDURES.....	19
7. FLYING DISPLAY PERFORMING	19
8. PHRASEOLOGY	20
9. DISPLAY HOLDING PROCEDURES	20
10. WEATHER MINIMA	21
11. DISPLAY CALLSIGNS.....	21
SECTION 7.....	22
DEPARTURE PROCEDURES	22
1. INTRODUCTION	22
2. ROUTES	22
SECTION 8.....	23
RADIO FAILURE, DIVERSION AIRFIELDS AND WARNINGS.....	23
1. RADIO FAILURE.....	23
2. DIVERSION AIRFIELDS.....	23
* See AIP Serbia/Montenegro and Annex D	23
3. SPECIAL WARNINGS.....	23
4. CONTROLLED EJECTION & JETTISON AREAS (Annex C).....	24

INTRODUCTION

1. "BATAJNICA 2012" INTERNATIONAL AIR SHOW

- The "BATAJNICA 2012" INTERNATIONAL AIR SHOW is show the Serbian Air Force is organizing and will provide spectacular flying displays with some of the world's famous aerobatic teams, single demo aircraft and a huge variety of impressive static aircraft displays trough the participation of various Air Forces, Aerospace Companies and organizations. Moreover, the public will witness many representative activities of the Serbian Air Force's operational capabilities, planned to take place throughout the show.
- "BATAJNICA 2012" will be held at Batajnica AFB (LYBT) from 31th August to 03rd September 2012. Batajnica AFB is the host base of the 101th, 252th Fighter squadrons, 890th Mixed helicopter squadron and 138th Transport squadron, one of the primary operational bases in Serbia.
- One of the primary aims of "BATAJNICA 2012" is to promote the tradition of Serbian aviation, the skill of flying aircraft, also to display the industrial achievements and the capabilities of the Serbian Air Force units and to provide the highest possible standard of entertainment for the public. In addition, it aims to foster friendship, cooperation and understanding among the many Services and Air Forces participating in "BATAJNICA 2012" from around the world.
- Basically, "BATAJNICA 2012" is planned according to STANAG 3533.

2. "BATAJNICA 2012" ACTIVITIES

- The air show "BATAJNICA 2012" is committed to marking the 100th Anniversary of the Serbian Military Aviation. The activities will primarily include dynamic displays on the ground and in the air through the participation of significant number of aircraft from the Air Forces and Aerospace Companies of many nations of the world.

3. PURPOSE AND VALIDITY OF THE "BATAJNICA 2012" DISPLAY ORDER

- THE PURPOSE OF THE "BATAJNICA 2012" Display Order is to provide all participants with necessary information regarding general policies for "BATAJNICA 2012", to outline operational and administrative aspects of "BATAJNICA 2012" and to focus on the various events of the Air Show.
- The Display Order will be available for all interested parties on the Internet site "BATAJNICA 2012" (www.airshow2012.vs.rs). Also, the Display Order will be sent to all the participants via official mail.
- The Display Order will be valid from 29th of August to 05th of September 2012.

4. HEALTH AND SAFETY

- All personnel have the responsibility to take reasonable care of the health and safety of themselves and any other persons who may be affected by their acts. They must cooperate with "BATAJNICA 2012" staff to ensure that all regulations, "BATAJNICA 2012" instructions, and safety procedures are adhered

to. "BATAJNICA 2012" staff are to brief all participants on the risk and control measures identified for their area.

- During times when aircraft are displaying, rehearsing or practicing vehicular and pedestrian movements in the airport maneuvering areas are to be limited to the absolute minimum. Vehicle movements across the maneuvering areas are approved only to operational staff that has the Batajnica ATC permission.
- During the aircraft operation in maneuvering areas, any vehicular and pedestrian movements are prohibited except for the purpose of operational support.

5. SECURITY

- All "BATAJNICA 2012" staff and participants have to ensure that the Air Show is conducted in a safe and secure environment. Therefore, it important to:
 - Maintain a high level of security awareness at all times.
 - Report any suspicious objects, bags, vehicles or people to the "BATAJNICA 2012" Security Forces ASAP.
 - Label any luggage and not leave it unattended under any circumstances.
 - Wear their "BATAJNICA 2012" personal passes at all times throughout their stay at Batajnica AFB.
 - Ensure that their "BATAJNICA 2012" vehicle pass is displayed prominently in their vehicle and under no circumstances deface, alter or wrongly exchange security passes.
 - Cooperate fully with the "BATAJNICA 2012" Security Forces and follow their instructions at all times.
- All volunteers, contractors, exhibitors and permanent staff will be required to have with them an official form of photographic identification at all times. This can be a passport, driver's license, I.D. or other official document.

6. PRESS STATEMENTS

- Members of the "BATAJNICA 2012" Executive Committee, Management, staff and participants should avoid making any statement to the Press concerning any incident without the approval of Display Director's Public Affairs or his representative. In the event of a Major Incident, the "BATAJNICA 2012" Display Director's or Public Affairs officer will initially release prepared press statements. Subsequently, and after consultation with the Display Director, a Press Officer and member of the "BATAJNICA 2012" Executive Committee will make further statements. Thereafter, the "BATAJNICA 2012" Display Director's Public Affairs will issue statements at intervals.

SECTION 1

COMMAND AND CONTROL

1. MANAGEMENT OF "BATAJNICA 2012" FLYING OPERATIONS

- The "BATAJNICA 2012" Display Director holds the overall responsibility for all flying activities and operational airfield issues during "BATAJNICA 2012". The "BATAJNICA 2012" Flight Operations Coordinator deputes the Display Director.

2. AIRCRAFT ADMINISTRATION

- From Monday 20th of August to Wednesday 5th of September inclusive, all arrangements for participating aircraft will be administrated from the Flight Centre in accordance with the procedures detailed in this Display Order.
- Participants will be given a unique authorization ("BATAJNICA 2012"/PPR - Prior Permission Required) number or/and airport slot. For states aircraft, the approval number will be the same as number of diplomatic clearance. This number should be quoted on all correspondence and communication related to "BATAJNICA 2012".
- Complete details of all VIP passengers should be send by e-mail or fax into Flight Operational Center "BATAJNICA 2012" before starting the flight to Batajnica airbase and confirm it during the first radio contact.

3. REGULATIONS AND FLIGHT CONTROL

- The "BATAJNICA 2012" Flying Control Committee has been appointed by the Chief of the Serbian AF&AD Command, to ensure that all aircraft commanders adhere strictly to the SAF Command approved "BATAJNICA 2012" Flying regulations, throughout the period 31st of August - 03rd of September 2012 inclusive.

4. AIR TRAFFIC CONTROL

- Serbia and Montenegro Air Traffic Services SMATSA Ilc Beograd is responsible for providing the service of air traffic.

5. COMUNICATION

- Contact details for "BATAJNICA 2012" are as follows:
- Before 29th of August and after 5th of September:

Ministry of Defense

Serbian AF&AD Command,

Air Show Section

Address: 1, Glavna Street

City: Belgrade-Zemun

Phone: 00 +381 11 31 64 277, Mobile phone: 00 +381 64 88 746 06

Fax: 00 +381 11 31 62 652

E-mail Address: airserbia2012@vs.rs



Web site: www.airserbia.vs.rs

- Between 29th of August and 5th of September:

Ministry of Defense

Serbian AF&AD Command

Air Show Section

204th AFB

Flight Centre

Participation Office

City: Batajnica

Address: Milenka Pavlovica bb Street

Phone: 00 +381 11 31 64 277

Mobile phone: 00 +381 64 88 746 06

Fax: 00 +381 11 31 62 652

E-mail Address: airserbia2012@vs.rs

Web site: www.airshow.vs.rs

SECTION 2

"BATAJNICA 2012" FLYING REGULATIONS

1. INTRODUCTION

- Throughout the flying activities it is the intention of the "BATAJNICA 2012" Flying Safety Control Committee to permit skillful and convincing displays. However, flying safety and the safety of the public are always to be of paramount importance and the primary goal. All participants should obey the following rules during their display and associated flying.

2. FIXED WING-VERTICAL SEPARATION

- Straight and level fly pasts including turns with an angle of bank up to 20 degrees are to be performed above 150 feet AGL.
- All aerobatic maneuvers, including inverted fly pasts and MANEUVERS, WHICH INVOLVE PULLING THROUGH THE VERTICAL, are to be executed above 450 feet AGL. Descent below 450 feet AGL is permitted when accomplishment of the maneuver is assured. For the purposes of this Regulation, slow speed, high angle of attack fly pasts are to be regarded as "aerobatic" maneuvers.
- All other maneuvers have to be completed above 300 feet AGL.

3. ROTARY WING AND GENERAL AVIATION-VERTICAL SEPARATION

- Straight and level fly pasts including turns with an angle of bank up to 20 degrees are to be performed above 100 feet AGL.
- Aerobatics will only be permitted by helicopters and general aviation which have a certified capability proven to the satisfaction of the "BATAJNICA 2012" Flying Safety Control Committee.
- Aerobatic and rolling maneuvers must be executed and completed above 300 feet AGL. Descent below 300 feet AGL is permitted when accomplishment of the maneuver is assured. Hovering and transition maneuvers may be performed below 100 feet AGL.
- Not more than one roll may be performed during any one pass.
- All maneuvers are to be completed above 100 feet AGL except hovering and transition maneuvers, which may be performed below 100 feet AGL.

4. FIXED WING-LATERAL SEPARATION

- All aircraft are to be flown no closer to the Spectator Enclosures than the 230m „No cross line“ (when the velocity vector is not towards the spectator enclosure) ([Annex D](#)).
- General aviation and helicopters should not be turned towards spectators enclosures unless the turn is completed any closer than Display line 1 ([Annex D](#)).
- When flying at speeds less 300 Knots IAS aircraft are not to be turned towards the spectator enclosures unless the turn is completed any closer than Display line 2 ([Annex D](#)).

- When flying at speeds equal or greater than 300 Knots IAS aircraft are not to be turned towards the spectator enclosures unless the turn is completed any closer than Display Line 3 ([Annex D](#)).

5. ROTARY WING-LATERAL SEPARATION

- All maneuvers are to be performed no closer to the Spectator Enclosures than the Display Line 1 ([Annex D](#)).

6. GENERAL RULES

- Engines are not to be shut down during flying demonstrations.
- No interlacing maneuvers are to be performed towards the Spectator Enclosures.
- Aircraft are not to be flown outside the aircraft's prevented limitations.
- Aircraft must not exceed True Mach Number (TMN) of M 0.95 or 600 knots IAS, whichever is the lower.
- Aircraft are strictly prohibited to fly over the Spectator Enclosures unless requested, in writing at least two (2) weeks before "BATAJNICA 2012" from the Display Director. This will only be granted for "non-aerobatics" maneuvers and only for single aircraft (not formation). Agreement to such an application may be subject to a validation flight before the "BATAJNICA 2012" Flying Control Committee.
- No one maneuver is to be attempted which is likely to jeopardize the safety of spectators in the event of mishap or misjudgment.
- A multi-engine aircraft must not fly below the speed at which it is possible to climb away, without change of configuration, should any engine fail to respond to an acceleration demand.
- Aircraft are not to fly outside the Display Zone (DZ) during their display sequence.
- Whilst carrying suspended loads helicopters must not be flown within such proximity to personnel, aircraft or buildings that hazard would be caused if the load were to become detached or control difficulties experienced during the flight. All such flying is to be carried out no closer to the Spectator Enclosures than the western edge of Runway 12 R-30L.
- Only maneuvers or sequences, which have been accepted by the "BATAJNICA 2012" Flying Control Committee, are to be performed. The "BATAJNICA 2012" Flying Control Committee is empowered to impose increased limitations on individual aircraft or aircraft display teams at its discretion.
- Pilots are to be thoroughly aware of the residential and sensitive areas surrounding Batajnica AFB, and especially Batajnica village, Banovci and Nova Pazova. In order to avoid disturbance in these areas, the following must be observed in the planning and execution of flight displays:
 - Low label aerobatic maneuvers must not be performed over these areas.
 - During demonstrations, aircraft must commence a climb from the minimum display height before crossing the "airfield boundary".
 - Aircraft approaching the airfield during their display must remain at a suitable height whilst over these areas and not descend to the minimum

display height for display maneuvers or fly-pasts until within the “airfield boundary”.

- Smoke generating devices are to be switched off prior of the final approach to land, low approach or touch and go.
- The use of pyrotechnics by aircraft during displays is prohibited, except on request, which is approved by Display Director.
- Use of chaff and flares during "BATAJNICA 2012" is prohibited, except on request, which is approved by Display Director.

7. AUTHORITY TO FLY AT "BATAJNICA 2012".

- Pilots must be in current flying practice on the type or types of aircraft they will be presenting. Pilots should be prepared to satisfy the "BATAJNICA 2012" Flying Safety Control Committee of their currency at the time of "BATAJNICA 2012" by presenting authenticated evidence of flying hours on type (or similar types) during the previous three months. Pilots must be in possession of a current Instrument Rating before he /she will be permitted to demonstrate aircraft under IFR conditions.
- All aircraft commanders and the Leaders of Aerobatic Teams are to confirm with their signatures that they are familiar with the content of this Display Order and eventual changes made during briefings.
- It should be noted that the "BATAJNICA 2012" Flying Control Committee would require participants to perform a full and/or flat display flight prior to displaying during the Air Show Day of September 2nd . If participants wouldn't perform the approval flight prior to Sunday, September 2nd, Flying Safety Control Committee (FCC) will preclude the participant from displaying on the Air Show.
- Participants, who are not that fluent in English, are to have a coordinator in the Air Traffic Tower who is familiar with Serbian or English, before a display, continuation/currency or approval flights are allowed to commence.

8. AIRCRAFT EQUIPMENT

- Non SAF participants are not authorized to display aircraft with live ammunition, rockets, bombs, external tanks containing fuel, or radio-active material in the aircraft Static Display, or carried on aircraft during the Flying Display. Equipment transmitting powerful electro-magnetic signals or lasers must not be operated during flight and in the Static Display, too.

9. CREW LIMITATIONS

- During any display or rehearsal flying, only the minimum number of crew required for the safe operation of the aircraft is to be carried.

10. AIRCRAFT DOCUMENTATION

- Commanders of aircraft participating in the Flying Displays are to present the following documents to the "BATAJNICA 2012" Display Director before taking part in any rehearsal or display flying at Batajnica AFB:
 - Pilot's License or Permit to Fly for the type of aircraft to be flown.
 - Current Certificate of Test or Experience.

- Current Medical Certificate.
- Valid Display Authorization by National Authorities (Air Force Headquarters)
- Certificate of Registration and Certificate of Airworthiness or equivalent.

11. BOOKING OUT

- Before any flight is made from Batajnica AFB during the period of air show "BATAJNICA 2012" or from any other airfield to take part in "BATAJNICA 2012", the full names of the persons on board the aircraft must be submitted to "BATAJNICA 2012" Flying Operations. The number of persons on board the aircraft must also be passed to Air Traffic Control during the initial start-up R/T call or first contact with Batajnica Air Traffic Control.

12. DAILY PRE-FLIGHT BRIEFING

- All aircraft commanders are to attend the flying display pre-flight briefing prior to participating in a Flying Display.
- At least the Team Leader/Team manager of Aerobatic Teams is to attend the flying display briefing.
- Aircraft commanders are to obtain a briefing from the "BATAJNICA 2012" Flying Safety Control Committee prior to any validation, rehearsal or practice flight.
- The "BATAJNICA 2012" Air Operations Coordinator and the "BATAJNICA 2012" Flying Safety Control Committee may undertake additional briefings in the Flight Centre.
- Mass Briefings will be held in the briefing room, the location of which will be determined additionally and upon their arrival in Batajnica AFB the participants will be informed of its location. Individual briefings will be held at locations which will be additionally determined and the participants will be informed about them in due time.
- The crews not located in Batajnica AFB are to receive the information from the display briefings in written form, not later than one hour before the beginning of the display.
- Specifically, a mandatory briefing for the REHEARSAL, on 1st and 2nd of September, will be given for team leaders and individual display pilots according to the following schedule:

- Welcome Briefing :	31 st August	14:00 UTC
- "BATAJNICA 2012" General Briefing :	1 st September	08:30 UTC
- "BATAJNICA 2012" Debriefing:	1 st September	14:00 UTC
- "BATAJNICA 2012" Main Briefing :	2 nd September	07:30 UTC
- "BATAJNICA 2012" Departure Briefing	3 rd September	07:30 UTC
- Revised briefing times will be available at the welcome reception or via your liaison officer.

13. BREACHES OF REGULATIONS

- Breaches of flying discipline are liable, in the first instance, to result in the pilot being required to terminate his display. Repeated or serious breaches will result in the pilot's suspension from the Flying Display for the remainder of the "BATAJNICA 2012".

SECTION 3

AIRFIELD AND AIRSPACE INFORMATION

1. AIRFIELD INFORMATION

ICAO LOCATION INDICATOR	LYBT
POSITION	445627.61N 0201502.62E
CLASSIFICATION	Military airport
ALTITUDE	86 meters
MAGNETIC DECLINATION	3°E
RUNWAY	12L-30R , 12R-30L, 11-29
TYPE OF TRAFFIC	OAT and GAT (military and civilian)
OPERATING HOURS	H24

* For the detailed information see [Annex C](#) of this document or [AIP Serbia](#).

2. AIRFIELD OPERATING HOURS & ASSOCIATED ACTIVITIES

DAY	DATE	TIME-UTC/GTM	ACTIVITY
FRIDAY	31 st AUGUST	0600Z – 1700Z	AIRFIELD OPERATIONAL Participants Arrivals
		1300Z – 1345Z	Welcome Briefing
SATURDAY	01 st SEPTEMBER	0600Z – 1400Z	AIRFIELD OPERATIONAL
		0600Z – 0800Z	Limited Arrivals
		0600Z – 0800Z	Serbian Aircraft Arrivals
		0830Z – 0900Z	Pre-flight briefing for rehearsal
		0930Z – 1330Z	Display Rehearsal / Validation Flights
		0930Z – 1400Z	Static Display
SUNDAY	02 nd SEPTEMBER	1400Z – 1430Z	Debriefing
		0430Z – 0830Z 1530Z – 1700Z	AIRFIELD OPERATIONAL
		0630Z – 0830Z	VIP Aircraft Arrivals
		0730Z – 0800Z	Main Briefing
		0910Z – 1400Z	International Flying Display
		0800Z – 1500Z	Static Display
MONDAY	03 rd SEPTEMBER	1530Z – 1700Z	Support / Charter Aircraft Depart
		0800Z – 1200Z	AIRFIELD OPERATIONAL
		0800Z – 1200Z	Support Aircraft Limited Arrivals
		0800Z – 1200Z	Flying and Static Display Aircraft Depart

3. TIME

- Local time/BST (A) (in Serbia in September) is UTC/GTM/Z plus 2 hours.
- "BATAJNICA 2012" Flying Operations will allocate precise arrival and departure times to all participating aircraft. **These times are to be strictly adhered to.**

4. COMMUNICATIONS

FREQUENCY DESIGNATION	CALL SIGN	FREQUENCY	HOURS OF OPERATION	REMARKS
APP TWR	BATAJNICA APPROACH	124,775 MHz	H24	-
GCA	BATAJNICA GCA	135,500 MHz	H24	-
GROUND	BATAJNICA GROUND	122.500 MHz	During DZ active	-
DISPLAY	BATAJNICA DISPLAY	134.00 MHz	During DZ active	-
RESERVE	BATAJNICA GROUND / DISPLAY	135,500 MHz	During DZ active	-

5. WEATHER INFORMATION

- Local Area Forecasts and Hourly Observations will be available at the Weather Desk at Batajnica Meteorological Office.
- En-route and destination forecasts required from return flights are to be booked at the Meteorological Office in Air Traffic Control of Batajnica.

6. AIRSPACE

- DISPLAY ZONE (DZ)** will be established for 1st and 2nd September during the hours stated at NOTAM.
- DZ** encompasses the borders from the surface to 6000m MSL. The borders DZ are as follows:

Designation and lateral limits	DZ 451229N 0201849E (Titel) 450843N 0202852E (Sakule) 445218N 0203852E (Pančevo) 444648N 0203417E (2KM SW from Kaluđerica) 445600N 0200941E (Vojka) 450600N 0195141E (Irig) 451013N 0200447E (Beška) 451229N 0201849E (Titel)
Vertical limits	GND / 6000 M AMSL

- Zones and Holding area (HA)** are given in [Annex D](#) and Section 6 of this Order.

SECTION 4

ARRIVAL PROCEDURES

1. INTRODUCTION

- All participants should obtain the appropriate Diplomatic and other clearances required by Serbia in accordance with procedures published in [AIP Serbia](#).
- Any participant requiring escort within BELGRADE FIR should notify the "BATAJNICA 2012" Flight Operational Center by fax 00 +381 11 3162652 or E-mail airserbia2012@vs.rs immediately upon receipt of this document.
- Aircraft are to fly at Altitudes in feet, meters or Flight Levels. Pressure settings in Serbia are transmitted in mmHg and hPa. Aircrews are expected to convert to other values as required. Aircraft are to adhere to allocated Flights Levels or Altitudes. Transition Altitude within FIR Beograd is 3050m or 10 000 Ft.
- VHF radios must be capable of operating up to 137.000 MHz with 25 kHz separation.
- Aircraft formation leaders are to report upon first contact with ATC the number of aircraft in the formation, and should fly less than 1nm distance within own formation with only leader aircraft squawking given SSR code. Aircraft are not to break formation within Airways. Therefore leaders must inform ATC of impending IMC. If they can't fly less than 1nm distance within own formation, aircraft are to separate and should fly more than 1nm distance between each other, and will be conducted as a single aircraft each.

2. ROUTES

- Aircraft entering BEOGRAD FIR, should establish initial radio contact, depending on the height and direction of arrival, with appropriate ATC service. All arrivals shall be conducted under STAR published in [AIP Serbia](#). All the procedures are detailed in [Annex C](#).

3. PLANNING AND ASSISTANCE

- If any further details are required concerning procedures within BEOGRAD FIR, please, contact ARO BATAJNICA telephone +381 11 31 06 210. The office is open 24 hours a day.

4. APPROACH PROCEDURES

- CKL BEOGRAD should lead aircraft toward entry points. After establishing two-way radio communication with ATC Batajnica, aircraft will be cleared to follow the appropriate procedure.
- In the event of inclement weather, GCA will monitor all IFR approach 12L in order to assist.
- Additional information can be found in [AIP SERBIA](#).
- In the event of an emergency, aircraft should use frequency for emergency 121,5 MHz.

5. INBOUND FLIGHT PLAN

- All aircraft inbound to Batajnica AFB are to file a standard ICAO Flight Plan.
- Full details of all VIP passengers are to be e-mailed or faxed to "BATAJNICA 2012" Aircraft Operations Department immediately prior to departure for Batajnica AFB and confirmed in the first radio call to Batajnica ATC.

6. PPR/"BATAJNICA 2012" REFERENCE

- Please include your "BATAJNICA 2012" REF/PPR (Prior Permission Required) number in the field 18 (RMK/text) of the FPL.
- Foreign state aircraft will instead of REF/PPR will use the number of diplomatic approval.

7. TRAFFIC PATTERN ([annex C](#))

- Pilots are advised that the I.P. height is 3000ft AGL and Break to land height is 1500ft AGL, with a maximum speed of 350kts IAS. Low Break upon request from Tower is 300ft AGL. Pattern for aircraft categories C, D and E, for the RWY 12L are left and for 30R are right. Pattern for aircraft categories A and B can be both right and left for all RWY. Helicopter shall use right pattern 12L and the left one for 30R. The over flight of the Spectator Enclosures is prohibited.

8. DIVERSION

- ATC on crew request or Display Director diverts aircraft to diversion airport.
- After landing the Aircraft Commander have to contact "BATAJNICA 2012" Flying Operations immediately to obtain a new Flow Controlled arrival time for Batajnica AFB.

SECTION 5

AIRFIELD OPERATIONS

1. INTRODUCTION

- Commanders of all aircraft operating into Batajnica AFB are warned that there will be considerable vehicular activity, including fuel trucks, sweeping vehicles and personnel on and around all taxiways and aircraft aprons. Extreme care is to be exercised at all times and especially when taxiing and at start up. Should assistance be required it may be obtained through "TWR BATAJNICA".
- After landing, aircraft will be at the frequency "TWR BATAJNICA" and will be escorted to their parking apron by a Follow-Me vehicle. At "BATAJNICA 2012", safety is paramount, so the Follow-Me vehicles are employed to ensure that there is no conflict between aircraft ground movements and any other people or vehicles on the airfield. On arrival at the allotted apron a Marshaller will meet and park each aircraft. Aircraft are to wait for the Marshaller's instructions before proceeding onto the apron. Parking space is very limited – participants are to TAXI SLOWLY and adhere strictly to the Marshaller's instructions at all times. Aircraft are parked at Batajnica AFB at their Aircraft Commander's risk.
- Participants are to ensure that at least one crewmember is on duty at their aircraft between 0800Z – 1500Z on September 2nd.

2. RAMP OPERATIONS, ENGINEERING SERVICES AND REFUELLING

- On arrival craft will be handled by members of the Maintenance Team. Where possible, crews are requested to ensure that a suitable tow bar is available, as asked so in the questionnaire sent in advance.
- Flight servicing will be the responsibility of the Aircraft Commander.
- The fuel shall be issued to participants during "BATAJNICA 2012" without reimbursement, if not another agreement, in accordance with timely stated needs of the participants.
- **Correct disposal of Waste POL will be strictly controlled. Aircraft Commanders having the necessity to dump any form of POL are to contact "BATAJNICA 2012" Maintenance Manager in order that the appropriate facilities can be made available.**
- Participants are responsible for any propeller swinging they might require.

SECTION 6

FLYING DISPLAY PROCEDURES

1. INTRODUCTION

- The "BATAJNICA 2012" International Flying Display will take place on Sunday, 2nd September, comprising 5 hours of continuous flying demonstrations. Saturday, 1st September will be for rehearsal/validation purposes.

2. FLYING DISPLAY –REHERSEAL FLIGHTS

- Individual display continuation/currency flights will be undertaken on Saturday, 1st September 2012, in the presence of the "BATAJNICA 2012" Flying Control Committee. Participating aircraft are to undertake their FCC approval flights on Saturday, 1st September to ensure they may display on Sunday, 2nd September. "BATAJNICA 2012" Flight Operations will confirm timings for these flights to participants upon arrival at Batajnica AFB.

3. FLYING DISPLAY PROGRAM

- The Flying Display program will not be finalized until much nearer to the date of "BATAJNICA 2012", due to the inevitable late changes in aircraft availability but will incorporate the various activities of the event.
- The "BATAJNICA 2012" Display Director will liaise closely in the planning phase with Aircraft Commanders taking part in the Flying Display.
- Upon arrival at Batajnica AFB, Commanders of aircraft participating in the Flying Display will be briefed on the daily Flying Display Program.
- Commanders of aircraft participating in the Flying Display, but not operating from Batajnica AFB, will receive a finalized Flying Display Program by e-mail or facsimile the day prior to the Display.

4. FLYING DISPLAY PLANNING

- Commanders of aircraft participating in the Flying Display, who wish to revise their flying display sequence or timings, as previously submitted on their "BATAJNICA 2012" Aircraft questionnaire, are to inform the "BATAJNICA 2012" Air Operations Coordinator immediately by e-mail on airserbia2012@vs.rs or facsimile +381 11 31 62 652.
- In certain circumstances, should a participant be prevented from performing a rehearsal or approval flight because of bad weather, participation in the Flying Displays may be restricted or cancelled.
- Display start time is based on either crossing the centerline of runway in use or releasing the breaks for a take off.
- Timing for the end of a display is to be based on either clearing the RWY after landing or exiting the DZ boundary.

5. PRE-FLIGHT BRIEFING

- On arrival, flying display participants are to visit the Display Director and a Flying Control Committee representative in the Flight Centre, and discuss timings for all display flights, briefing procedures and obtain any updates to the "BATAJNICA 2012" Flying Regulations.
- Commanders of aircraft not-located at AFB Batajnica have to contact the Coordinator of Operations team by phone at least two hours before the time allotted to them and thus receive telephone briefing from him.

6. BOOKING OUT AND INITIAL PROCEDURES

- Call "BATAJNICA GROUND" before startup or 20 minutes before actual display time, whichever is earlier, and advise ATC of aircraft serviceability and confirm number of persons on board.
- After the initial call on "BATAJNICA GROUND" aircraft will remain on this frequency until the Commander of the aircraft reports ready for T/O to the holding point.
- After that the ATC will transfer the aircraft to the BATAJNICA Display Frequency. T/O Clearance-Flying Display and Landing will be at the Display Frequency.

7. FLYING DISPLAY PERFORMING

- It is expected that by keeping all aircraft on the Display frequency will assist pilots to minimize delays between display items. If prolonged holding is expected, or requested, aircraft may be transferred to another frequency.
- Accurate display timing is essential. Unless otherwise instructed, participants are to keep rigidly to allotted display times. "BATAJNICA GROUND" will inform if the display is running early or late.
- In the event of an emergency situation during the Flying display, commanders of display aircraft may be instructed to immediately stop their display. In this event, further instructions will be given on "DISPLAY" frequency to either divert to another airfield, to continue flying fly pasts at Batajnica AFB not below a specified minimum height, or to land.
- During all flying displays no transmissions are to be made on the display frequency other than by Display director, operational staff with approval and the displaying aircraft.
- Prior to any flying display a representative of the aircraft participating in the aircraft participating in the display is to be present at the Fire Brigade Station in front of the Control Tower throughout the display. He will be the technical consultant in case of than accident and will escort the emergency response team to the scene of the accident.
- Should an emergency situation arise, participants are expected to explain to ATC the problem and their intentions.
- It is important for displaying aircraft to notify ATC prior to turning downwind for either "LANDING / TOUCH AND GO / LOW APPROACH".

8. PHRASEOLOGY

- The following standard R/T phraseology is to be used, during the Flying Display:
 - A. **ATC- DISPLAY RUNNING** (time in minutes) **LATE**.
 - B. **AIRCRAFT- DOWNLOAD TO LAND/TOUCH AND GO/LOW APPROACH**. (My intention is to land/touch and go or low approach).
 - C. **AIRCRAFT- ABORT, ABORT, ABORT** (My take off is to be aborted).
 - D. **AIRCRAFT- REQUEST DIVERSION** (I need to divert to another airfield).
 - E. **ATC- FLUING CONTROL COMMITTEE INSTRUCTS YOU TO LAND** (Land as soon as possible and report to the "BATAJNICA 2012" Flying Display Manager in the Flight Centre).
 - F. **ATC- STOP, STOP, STOP**. (End the flying display immediately and await further instructions from Batajnica ATC).
 - G. **ATC- DIVERT TO...** (ATC indicating that due to certain conditions aircraft need to divert to a specified airfield).

9. DISPLAY HOLDING PROCEDURES

- **HOLDING INDIA**
 - A left hand orbit in the course 127°M which should be executed at IA 485 (450235.1N 0200423.2E)
 - Caution whilst Holding :
 - a) Minimum altitude 600M (2000ft)
 - b) Operations at low level not above 300M (1000ft) QFE.
 - c) Maintaining a good lookout at all times.
- **HOLDING AREA UNIFORM**
 - A zone with the center 450810N 0201636E diameter 7KM (3.9 nm), left orbit
 - Caution whilst Holding:
 - a) Minimum altitude 600M (2000ft)
 - b) Operations at low level not above 300M (1000ft) QFE
 - c) Maintaining a good lookout at all times.
- **HOLDING AREA OSKAR**
 - A zone with the center 445303N 0203028E diameter 4.5KM (2.4 nm), right orbit
 - **Caution whilst Holding :**
 - a) Minimum altitude 600M (2000ft)
 - b) Operations at low level not above 300M (1000ft) QFE.
 - c) Maintaining a good lookout at all times.
- **HOLDING AREA VIKTOR**
 - A zone with the center 445618N 0201111E diameter 1KM (0.5 nm), applied for the basic aviation and helicopters, right orbit
 - **Caution whilst Holding:**
 - a) Minimum altitude 250m (830 ft) QFE
 - b) Maximum altitude 500m (1650 ft) QFE
 - c) Maintaining a good lookout at all times.

10. WEATHER MINIMA

Type of Maneuvers	Number of Aircraft	Rotary-wing		VSTOL (power borne)	Fixed-wing	
		(1)	(2)		(1)	(2)
Fly Past (straight and level)	1	1.0		60 (200)	3.7	300 (1000)
	2 - 6	1.5		100 (300)	3.7	300 (1000)
	7 - 16	1.5		100 (300)	3.7	450 (1500)
	over 16	1.5		100 (300)	8	600 (2000)
Aerobatic Flat Show (no vertical maneuvers)	1	3.7		300 (1000)	3.7	300 (1000)
	2 - 6	3.7		300 (1000)	3.7	300 (1000)
	7 - 16	3.7		300 (1000)	3.7	450 (1500)
Aerobatic Full Show	As issued by Display Director					

NOTE : Aircraft unable to display because of low cloud base may fly an instrument approach to land, touch-and-go or low approach.

- Upon arrival at Batajnica AFB, participants should provide the "BATAJNICA 2012" Display Director with copies of the display weather minima as laid down by their operating authority. The more restricted values will apply.
- In the event of adverse weather conditions, allotted display timings are to be adhered to. Display Director will advise any alterations to the flying program. The "BATAJNICA 2012" Flying Control Committee is empowered to restrict or cancel any display due to adverse weather conditions. In the event of flying being prohibited it is requested that participants taxi along the runway during their allocated display time for the benefit of the public.

11. DISPLAY CALLSIGNS

- Call signs for all participants will be followed by the number allocated in the daily flying schedule. Exceptions can apply, granted by the Display Director.

SECTION 7

DEPARTURE PROCEDURES

1. INTRODUCTION

- All departure flights are to file a standard ICAO Flight Plan at ARO BATAJNICA upon arrival at Batajnica whether planning to depart IFR or VFR.
- Departure times will be confirmed by "BATAJNICA 2012" Flying Operational Center after 1530Z on Sunday, 2nd September.

2. ROUTES

- All departure flights will be managed according to [AIP Serbia](#).

NOTE: It is prohibited to fly under VFR rules below 2000 feet AGL over villages, towns in Serbia.

SECTION 8

RADIO FAILURE, DIVERSION AIRFIELDS AND WARNINGS

1. RADIO FAILURE

- To the aircraft which inbound from other airports to perform flight display with communication failure the entry into DZ is forbidden.
- Inbound/Outbound: Follow standard ICAO Procedures. Squawk Mode 3/A 7600 with Mode C.
- Display Aircraft shall discontinue sortie, maintain VMC and land. This aircraft has to follow standard ICAO procedures.
- Standard light signals from the Tower are to be obeyed.

2. DIVERSION AIRFIELDS

ICAO LOCATION IDICATOR	LYKV
POSITION	434905.17N 0203509.93E
DISTANCE FROM LYBT	127.4km(68.8 nm) in the course 164°M
CLASSIFICATION	Military airport
ALTITUDE	147 ft
MAGNETIC DECLINATION	4°E (2010)
RUNWAYS	14/32
TYPE OF TRAFFIC	GAT (civilian and military) and OAT
WORKING HOURS	H24

* See [AIP Serbia/Montenegro](#) and [Annex D](#)

3. SPECIAL WARNINGS

- Commanders of all aircraft participating in "BATAJNICA 2012" are to comply with the "BATAJNICA 2012" Flying Regulations as detailed at Section 2 to this Display Order.
- The teams/participants may have accompanying Air Force coach who will be located in the defined area and, if needed, give information and orders to the participants. Commanders of aircraft shall submit the data on Air Force coach to the Coordinator of Operations team.
- Avoidance Areas: There are many sensitive areas such as schools, hospitals, farms, in the vicinity of Batajnica AFB. In particular, please be aware to:
 - Avoid turning/maneuvering over the village of Batajnica located 2,3nm south-east from the Datum point of the airfield.
 - Avoid turning/maneuvering over the village of Nova Pazova located 0,8nm to the west of the Datum point of the airfield.



- Avoid the communication tower of the height 144 feet located 0,7nm to the south of the Datum point of the airfield.

Airfield Warnings:

- **DO NOT FLY AT LOW ALTITUDE OUTSIDE OF THE AIRFIELD BOUNDARY.**
- **DO NOT OVERFLY the Spectator Enclosures.**
- Lookout for bird activity on and around Batajnica AFB (even though all available means have been implemented, birds are still present randomly at the vicinity of the airfield).
- Aeronautical Publications, Charts and NOTAMs should be consulted prior to arriving/flying at Batajnica AFB. Further information and copies of relevant NOTAMS can be obtained from "BATAJNICA 2012" Flying Operations or ARO Batajnica.

4. CONTROLLED EJECTION & JETTISON AREAS ([Annex C](#))

- The area for the controlled ejection and jettison areas is Čenta training area LYD-13 or upon the decision of the Display Director.

Publisher

Serbian AF&AD Command

Authors

Lt Col Bozidar Cmiljanovic, pilot, AF&AD Command

Lt Col Milan Jelic, pilot, AF&AD Command

Major Dejan Beda, pilot, 204. air base

Expert team of ATC SMATSA

Graphic Preparation

Printed by

Printed in

2012